




1. Click here to download the firmware
2. When the download screen appears, select **Desktop** as the destination and click **Save**




3. Once file is successfully downloaded open a web browser to www.routerlogin.net or <http://192.168.1.1>
3. Enter your user name and password. **Note:** *The user name and password is case sensitive*
 - The default user name is: **admin**
 - The default password is: **password**



4. Click the **Advanced** tab
5. Click **Administration**
6. Click **Firmware Upgrade**
7. Click the **Choose File** button



8. Choose the firmware file you saved to your desktop and click the **Open** button



9. Click the **Upload** button and click **Yes** to confirm

Firmware Upgrade

Check for new version from the Internet.

Locate and select the upgrade file on your hard disk.

CharterFirmware.chk

The router will load the firmware. **DO NOT** power off the router during this process. Once complete the router will reboot and the web page will refresh once the device has completed the reboot process.

You can verify the update completed under router information or router firmware version in upper right corner.